



Sagoma gonfiabile LISKI PRO-AIR



Inflatable shape LISKI PRO-AIR

Note per il montaggio

1. Spiegare l'articolo completamente prestando attenzione ad evitare il contatto con oggetti appuntiti o taglienti, trovando un posto libero da pietre, ghiaia e oggetti taglienti.
2. Riempire totalmente il fondo della sagoma con acqua (aggiungere l'antigelo nella stagione invernale)
3. Non usare la sagoma in caso di acqua ghiacciata nel serbatoio
4. Gonfiare l'articolo non oltre il 90% del volume, fino ad una pressione massima di 0,04 bar.
5. Non gonfiare eccessivamente: l'eccessiva pressione potrebbe provocare il danneggiamento della sagoma e la rottura delle saldature.
6. Per sgonfiarlo premere lateralmente sulla base della valvola oppure inserire un tubetto per far defluire l'aria
7. Non lasciare la sagoma esposta inutilmente al sole, acqua, vento e nelle vicinanze di carburanti e solventi (auto, furgoni, ecc)
8. Per movimentare la sagoma, utilizzare entrambe le maniglie sollevandola dal terreno, evitando assolutamente il trascinarsi.
9. Controllare periodicamente la pressione d'aria; in caso di danneggiamento usare l'apposito kit di riparazione.
10. Conservare le istruzioni per future referenze

Assembling notes

1. Spread out the item completely, paying attention to avoid the contact with sharp objects, finding a free place from stones or gravel
2. Fill in the shape totally with water (add in antifreeze water during the winter season)
3. Don't use the shape in case of freezing water in the tank
4. Inflate the item not more than 90% of volume, until a maximum pressure of 0,04 bar
5. Don't inflate excessive: Too pressure can cause the shape damage and the welding breaking
6. To deflate push on the valve base or fill in a little pipe to let air flow
7. Don't let the shape exposed to the sun, rain, wind and near to fuel and solvent (cars, van ecc.)
8. To moving the shape use the both handel pulling up from the ground, to avoid absolutely the entrainment
9. Control periodically the air pressure; in damage case use the recovery kit
10. Preserve the instruction for future reference

